


AA56



AA56

Wall Plate Remote Pickup for PX

INSTALLATION



1. Connect tubing between the fitting on the PX sensor and the fitting on the back of the AA56.



2. Mount the wall plate onto the wall in the area to be monitored.

NOTICE

- This product is not intended for life or safety applications.
- Do not install this product in hazardous or classified locations.
- Read and understand the instructions before installing this product.
- Turn off all power supplying equipment before working on it.
- The installer is responsible for conformance to all applicable codes.

PRODUCT IDENTIFICATION

AA56 Remote pickup wall plate

OPERATION

Use the AA56 with the PX series dry media differential pressure transducer when the PX is not mounted in the area that needs to be monitored. Mount the AA56 in the testing area and connect it to the PX with tubing.